

WALLPAPER INSTALLATION GUIDE

ONE FEATURE WALL APPLICATION

PREPARATION

WHAT YOU'LL NEED

- Utility knife
- Measuring tape
- Level or laser
- Pencil
- Plastic squeegee (included)
- Ladder

IMPORTANT!
WE KNOW YOU'RE
EXCITED TO APPLY THE
WALLPAPER, BUT IT'S
IMPORTANT TO LET THE
ADHESIVE REST (AT 17
°C +) FOR AT LEAST 24
HOURS BEFORE
APPLICATION.

WALL SURFACE

1. The surface must be smooth, clean, and dry.
2. Any paint on the wall must have been dry for at least 14 days before applying the wallpaper.
3. The wallpaper should not be applied on a primed surface or on plaster that hasn't been sanded or painted.
4. The surface must be cleaned with a dry cloth (without any cleaners) and be free of dust and other impurities.
5. The surface must be completely smooth.
6. Any imperfections on gypsum walls must be repaired before installing the wallpaper. If using plaster, let it dry completely. Any repaired area must be sanded to have a smooth, dry, and non-porous surface.
7. Any wall plates or other objects that could hinder application must be removed before applying the wallpaper.

APPLICATION

HERE WE GO!

1. Unroll a first panel on a clean floor, pattern side down.
2. Peel off the first six inches of wax paper from the top and fold.
3. Starting from the left side, align the top of the panel to the top of the wall. The adhesive should overlap the ceiling by an inch, in case it isn't levelled. It's important to pencil in your one-inch guides at the top and side of the panel.
4. Make sure that the panel's right side is levelled so that the following panels can be as well.
5. Using the plastic squeegee, affix the top of the panel with long, horizontal strokes, starting from the middle to the edges. Scrape any bubbles off towards the edges. Peel off another 12 inches of wax paper straight down with both hands. Avoid scraping the area where the wax paper is folded.
6. Repeat step 5 until the whole panel is fixed to the wall.
7. Pencil in small guides on the affixed panel, ½ inch from the edge. The wallpaper panels are designed to overlap by a ½ inch.
8. Unroll a new panel and peel off the first six inches of wax paper from the top and fold (like in steps 1 and 2).
9. Adjust the second panel on the pencil marks, making sure to line up the patterns, affix the top of the second panel and repeat the previous steps until the entire surface is covered. Note: take your time! Our removable material allows you to peel off and reapply the wallpaper panels, so don't worry if you need to realign the pattern.
10. Using the squeegee, press any corners where excess vinyl needs to be removed (such as the ceiling, floor, or right wall).
11. To finish it off, remove the excess vinyl with a utility knife.

Enjoy your stunning feature wall!

WALLPAPER INSTALLATION GUIDE

FULL ROOM APPLICATION

APPLICATION

HERE WE GO!

1. Unroll a first panel on a clean floor, pattern side down.
2. Peel off the first six inches of wax paper from the top and fold.
3. Starting from the left side, align the top of the panel to the top of the wall. The adhesive should overlap the ceiling by an inch, in case it isn't levelled. It's important to pencil in your one-inch guides at the top and side of the panel.
4. Make sure that the panel's right side is levelled so that the following panels can be as well.
5. Using the plastic squeegee, affix the top of the panel with long, horizontal strokes, starting from the middle to the edges. Scrape any bubbles off towards the edges. Peel off another 12 inches of wax paper straight down with both hands. Avoid scraping the area where the wax paper is folded.
6. Repeat step 5 until the whole panel is fixed to the wall.
7. Pencil in small guides on the affixed panel, ½ inch from the edge. The wallpaper panels are designed to overlap by a ½ inch.
8. Unroll a new panel and peel off the first six inches of wax paper from the top and fold (like in steps 1 and 2).
9. Adjust the second panel on the pencil marks, making sure to line up the patterns, affix the top of the second panel and repeat the previous steps until the entire surface is covered. Note: take your time! Our removable material allows you to peel off and reapply the wallpaper panels, so don't worry if you need to realign the pattern.
10. Using your squeegee, press down on the corners where excess vinyl needs to be removed (e.g., at the ceiling, the floor, or on the right wall)
11. To finish, trim the excess from the ceiling and the floor with a utility knife.

Corner Preparation:

When handling corners, measure the distance from your last strip to the corner at various heights to account for uneven walls, and cut the next strip wider to ensure coverage. Overlap the wallpaper slightly into the corner, smoothing it firmly, and fold it over to the adjoining wall without creases. Trim any excess material for a neat finish. This approach helps maintain a seamless appearance, ensuring the pattern flows smoothly around the corner.

Revel in your newly transformed space, and don't forget to celebrate your accomplishment!

TIPS FOR MAINTENANCE

Maintain the beauty of your wallpaper by gently cleaning it with a damp cloth when needed. Avoid using abrasive cleaners to keep the design vibrant and intact.

Don't hesitate to contact us if you have any questions during or before the installation. We're here to help. Contact us at info@artza.ca.